

# **RJB MicroTouch Teat Dip Pump™ 10-15000**

This easy to install electric pump automatically supplies dip to the drops in the parlor or flat barn. The pump is installed simply by hanging it on a wall using the four holes at the base of the pump. Connect the intake filter line and place it in your barrel of teat dip. Then connect the fluid-out line to the clear plastic hose that goes to the milking barn. The power may be turned off at the end of milking by unplugging the power cord. The pump runs automatically to maintain pressure to the drops.

The MicroTouch Teat Dip Pump has several accessories available to customize your in-parlor teat dip distribution.

The MicroTouch Teat Dip Pump is available in either 110 volt or 220 volt power. The 110 volt model has the standard U.S. UL approved plug and the 220 volt model is available with the Australian or UK plug. The cord can also be ordered without a plug.

If the RJB Electric Teat Dip Pump does not fit your installation requirements, please review our complete line of iodine or chlorine based teat dip pumps. We make pumps which will dispense ready-to-use products, two part solutions, or concentrates.



L-100

RJB Company  
1641 Princeton Ave #6  
Modesto, CA 95350  
Phone 209-527-6060  
Fax 209-527-0622  
e-mail [RJB@RJB-Brand.Com](mailto:RJB@RJB-Brand.Com)  
[www.rjb-brand.com](http://www.rjb-brand.com)

**Distributed By:**