

COLD-WAR™



PRODUCT DESCRIPTION

Cold War™ is a premium multi-temperature powdered formulation for mechanical and CIP cleaning of dairy equipment.

BENEFITS

Promotes Quality Assurance

- Superior cleaning even under the most challenging conditions.
- Assures effective clean up, even in 100°F (38°C) water, and when hot water heater fails.

Saves Money and Time

- Reduces hot water consumption and energy costs.
- No additional additives needed for water conditioning.
- High actives formula provides superior use-cost.

Environmentally Responsible

- Low phosphate levels.

Cold-War™

PROPERTIES

Form powder
Color white with blue specks
Foam low, fast breaking
Wetting ability excellent

Alkalinity
Active as Na₂O 32.9%
Total as Na₂O 53.2%
Available chlorine 2.0%
pH (1.0% solution) 12.3
(0.4% solution) 11.9

Formula ingredients contain not more than 1.2% phosphorus,
0.2 grams per gallon of average recommended use concentration.

TO USE

CLEANING PIPELINES AND MILKING UNITS

1. Preflush pipeline and milking units with large volume of clear tap water.
2. Prepare cleaning solution using 1 ounce of *COLD-WAR* to each 3 gallons (2.5 g/L) of warm water. (Starting temperature 100°F/38°C) (Do not guess at amount of water. Measure and put mark on tank.) In water over 20 grains hardness, use 1 ounce of *COLD-WAR* to 2 gal (3.8 g/L) water.

NOTE: Pipeline systems with restrictions resulting from the installation of milk meters, automatic takeoffs, unit washers and other plastic accessories, may require a higher starting temperature and/or product concentration.

3. Circulate cleaning solution through system for 10 minutes, brush-washing all parts not coming in contact with circulating solution. Wear rubber gloves when brush-washing equipment.
4. Rinse with a large volume of tap water to remove all detergent solution. Follow with proper use dilution of *MANDATE-LT* to acid rinse and sanitize in one easy step. Or use proper use dilution of *PASSIV-8*, *PL-10* or *KLEER-SHEEN*. Circulate. Allow to drain.
5. Unless *MANDATE-LT* was used to acid rinse and sanitize in last step, just before milking, sanitize by circulating proper ppm solution of a liquid sanitizer, following label directions.* (Do not sanitize more than 30 minutes before using equipment.) Drain completely.

NOTE: When step 4 is followed, alternate acid cleaning with *PASSIV-8*, *KLEER-SHEEN* or *PL-10* is not necessary. The acidified rinse prevents formation of milkstone, mineral deposits and leaves surfaces film-free.

CLEANING TRANSFER SYSTEMS

Fill receiver container with enough warm water to establish recirculation. Add 1 oz. of *COLD-WAR* per each 3 gallons (2.5 g/L) of 100°F (38°C) water. Follow pipeline cleaning procedures.

MECHANICAL CLEANING OF BULK TANKS

1. Pre-flush tank with large volume of clear tap water.
2. Prepare washing solution in volume necessary to properly operate the spray devices, using 1 ounce of *COLD-WAR* to each 2 gallons (3.8 g/L) of warm water (100°F/38°C). In water over 20 grains hardness, use 1 ounce *COLD-WAR* to 1 gallon (7.5 g/L) of water.
3. Allow to spray-wash for 10 minutes. Disconnect return line and drain.
4. Inspect all milk zone surfaces for cleanliness. Prepare concentrated washing solution, using 4 oz. *HC-10* and not more than 1 gallon (30.0 g/L) of hot water. Brush-wash valve, outside of tank and any part of tank not cleaned by mechanical system. Wear rubber gloves when brush-washing equipment.
5. Rinse tank thoroughly inside and out with clear water. Follow with proper use dilution of *MANDATE-LT* to acid rinse and sanitize in one easy step. Or use proper use dilution of *PASSIV-8*, *PL-10* or *KLEER-SHEEN*. Circulate. Allow to drain.
6. Unless *MANDATE-LT* was used to acid rinse and sanitize in last step, just before milking, sanitize by spraying with proper ppm solution of a liquid sanitizer.* Allow tank to drain before closing valve.

NOTE: When step 5 is followed, alternate acid cleaning with *PASSIV-8*, *KLEER-SHEEN* or *PL-10* is not necessary. The acidified rinse prevents formation of milkstone, mineral deposits and leaves surfaces film-free.

*Where local or state regulations are in effect, consult authorities for additional information.

Consult your Ecolab Representative for specific use instructions and recommended dispensing equipment.

For cautionary and first aid information, consult the Material Safety Data Sheet (MSDS) or product label.

FOOD & BEVERAGE DIVISION

Ecolab Inc.
370 Wabasha Street N.
St. Paul, Minnesota 55102-1390 U.S.A.
www.ecolab.com 1-800-392-3392

© 1999 Ecolab Inc. Printed in U.S.A. 13860/0307/1099
All Rights Reserved

