

CLEAN-A-LOBE™

VACUUM PUMP DETERGENT

CLEAN-A-LOBE is a foaming detergent for use in lobe-style vacuum pumps. It cleans, removes oxidation, and mineral scale, and protects by inhibiting corrosion.

FEATURES/BENEFITS

- Pump runs more efficiently, reducing power draw
- Pump runs smoother and more quietly
- Pump life is extended

PROPERTIES

Appearance:	Clear, colorless liquid
Density:	8.5 lbs/gallon
pH:	6
Odor:	None
Foam:	High foam

USAGE GUIDELINES

DIRECTIONS FOR USE:

Turn on the vacuum system. When operating vacuum has been achieved, place the open end of the flushing tube into the container of **CLEAN-A-LOBE**.

Allow the product to be drawn into the pump.

Continue running the pump for 10 minutes after the moisture stops coming from the pump exhaust. Turn off the vacuum pump until the next milking.

www.chemstarworks.com



CLEAN-A-LOBE™

VACUUM PUMP DETERGENT

SAFETY INFORMATION

In case of emergency, **CALL 1-800-424-9300**

DANGER

- Keep out of the reach of children
- May cause death if swallowed
- Harmful if inhaled
- Causes severe eye irritation
- Causes severe skin irritation or burns
- Contains hydrogen peroxide and peroxyacetic acid
- See below for additional precautions and/or consult material safety data sheet

PRECAUTION

Contact with this product may cause irritation to skin and eyes. Protect eyes, skin and clothing from contact with product. When handling, wear chemical goggles, rubber boots, rubber apron and rubber gloves to prevent injury. Keep container tightly closed when not in use. Store container in a locked cabinet or room to keep it out of the reach of children. Use with adequate ventilation. Wash thoroughly after handling product.

FIRST AID

External:

In case of contact, immediately flush contaminated skin with plenty of water for at least 15 minutes. Remove contaminated clothing and shoes while flushing with water. If irritation or burn occurs, call a physician.

Internal:

If conscious, dilute by giving several glasses of water or milk. Do not induce vomiting. If vomiting does occur, repeat giving several glasses of water or milk. Get prompt medical attention. **Never give anything by mouth to an unconscious person.**

Eyes:

Immediately flush with plenty of clean, running water for at least 15 minutes, holding eyelids apart to ensure flushing of the entire eye surface. Call a physician.

Inhalation:

Remove to fresh air. Get medical attention.

SPILL PROCEDURES

In case of small spill (less than one gallon), flood area with a large quantity of water. For larger spills, contain and remove with inert absorbent and dispose of according to federal, state, and local laws.

STORAGE & WASTE DISPOSAL

Store this product in a cool, dry area away from direct sunlight and heat to avoid deterioration. Store in a locked cabinet or room to keep it out of the reach of children. Dispose of only in compliance with federal, state, and local laws.